

# INSTALLATION INSTRUCTIONS

## Installation instructions for Dodge 1500 DD-19335 Front Bumper

**\*\* Inspect bumper and all parts prior to installation. Contact us at 951-808-0750 for missing parts.**

### Removing Factory bumper:

1. Disconnect fog lights.



2. Remove 4 bolts securing bumper to frame. Retain Hardware for installation. Remove bumper at this time



### Bumper Installation for DD-19335:

**We recommend you have help with lifting of the front bumper to avoid injury or damage to bumper and vehicle.**



# INSTALLATION INSTRUCTIONS

- 1 If installing a winch install at this time. Mount auxiliary lights at this time.
- 2 Install reusing Factory hardware at factory locations.
- 3 Check alignment to body and tighten all hardware at this time.

**Note: Recheck all hardware after the first couple hundred miles. It is advised the inspect the bumper and hardware**