



# INSTALLATION INSTRUCTIONS

## Installation instructions for DG-2962 Dodge Ram winch bumper

Inspect bumper prior to installation. Contact Body Armor directly if missing any items 951-808-0750

### Hardware List:

1/2" Hex bolts: Qty: 8  
1/2" Hex nuts: Qty: 8  
1/2" Flat washers: Qty: 16  
1/2" Lock washers: Qty: 8

### Kit Includes:

Rear bumper  
Light brackets (Left and right)

### Removing Factory front bumper:

Step 1 Unplug back up sensors from harness. Unplug license plate lights and towing harness from plug

Step 2 Loosen the 8 bolts and remove factory bumper. Do not remove the hitch.

### Prep Body Armor bumper for installation:

Step 1 Remove the hitch wiring plug from the factory bumper, attach in the BA bumper. Our opening may be on the opposite side of the OEM bumper. If this is the case you will need to release the factory harness and move to the other side.

Step 2 Attach license plate prior to installation. We do not provide license plate lights.

Step 3 We recommend using LED license plate bolts, easy to find at any auto parts store

Step 4 Install the backup sensors in the same positions as they were on the OEM bumper.

NOTE: This is a full-sized bumper, it is heavy, we recommend having help when installing.

### Installing front bumper:

Step 1 Locate the light bracket plates. This bracket will be sandwiched between the bumper and the frame horns. The light tab will be towards the outside of the frame horns under the slotted holes in the bumper. You can mount BA lights PN 30033

Step 2 Insert the 1/2" bolts through the frame horns, through the light brackets and into the bumper. Use a flat washer against the head of the bolt and on the nut side as well. Lock washers are next to the nut. Keep hardware loose until all hardware is attached. Once alignment is confirmed tighten all hardware.

Note: Re-check hardware after about 500 miles to confirm tightness.