



INSTALLATION INSTRUCTIONS

Installation instructions for Toyota Tundra Double Cab TN-4121 Rock Rails

Fits 2007-2012 Toyota Tundra Double Cab

**** Inspect Trail steps and all parts prior to installation. Contact us at 951-808-0750 for missing parts.**

Hardware list:

QTY 16 M8X1.25X30mm
QTY 16 M8X1.25X25mm
QTY32 M8 washer

Installing Trail Steps:

We recommend you have help with lifting of the Trail Steps to avoid injury or damage to Trail Steps and vehicle.

- 1 If vehicle Has factory steps, remove at this time
- 2 Install step brackets to Rock Steps using M8 hardware.



- 3 Mount Trail Steps to Factory Step mount locations. Leave loose at this time. (If vehicle was not equipped with factory step, look for holes plugged with plastic screws or bolts from factory.)

INSTALLATION INSTRUCTIONS



- 4 Check alignment to body and tighten hardware.
- 5 **Note: Recheck all hardware after the first couple hundred miles. It is advised to inspect the steps and hardware periodically.**

** The RockSteps are painted with a dual process black powder coat. The E-Coat base is designed to prevent rust from spreading under the powder coat paint. It does not prevent rust from occurring. The RockSteps are manufactured from steel, rust can develop if not properly maintained, this not considered a warranty issue. It is the responsibility of the user to touch up scratches. The paint is warranted from manufacturer defect, such as peeling or bubbling, for 90 days from date of purchase.

Poly Step Pads are now available for the Rock Steps

Part Number 5123 sold as a set of 4 pads

Contact your Body Armor dealer to order your set.